




PanelView Standard/Plus Interface Upgrades

*for your KRDIIe,
Pan-O-Mat, ADD Operator Interfaces.*



PanelView Plus 1250



PanelView Plus 700



Before



- ▼ *Be ready for tomorrow's Operator Interface capabilities and cutting edge graphical information displays.*
- ▼ *Enhance machine information and diagnostics by upgrading your PanelMate or existing interfaces.*
- ▼ *Allow our experts to make the seamless integration and upgrade to your existing application and machine configuration.*



PanelView Standard/Plus Interface Upgrades

for your KRDIle, Pan-O-Mat, ADD Operator Interfaces.

Upgrade your machines with new PanelView Standard or Plus Terminals!

Why Upgrade?

As your existing equipment becomes older and less reliable, it could severely affect your plants productivity. PanelMate and CRT Terminals are virtually obsolete and extremely hard to replace.

To keep your plant running at optimum levels, you need readily accessible information, and a stable, reliable platform to allow operators to interface with that information in order to maximize productivity.



PanelView Standard Model 600 Color

PanelView Standard Monochrome 300 Micro

New, Better Technology with the PanelView Plus Operator Terminals

Be ready for your plants increasing manufacturing and equipment information demands. PanelView Plus Terminals offer new, brighter, powerful, energy efficient, LCD graphical displays capable of producing Trending information, Expressions, Data logging, and Animations!

Flexible Communications Protocols!



PanelView Plus Touchscreen Interfaces

We Have The Right Solution For You.

Let our expert Service Engineer's handle a seamless integration into your existing application and machine configuration.

1. Select your PanelView Standard/Plus Interface(s) 550, 600, 700, 1000, 1250, 1500.
2. Select Stainless Steel Enclosure (optional) with new AIC Module(s), Push Buttons, Contact Blocks, Cables, and Compact Flash Card(s).
3. We'll handle the programming of new components.
4. Update the electrical documentation.
5. Modification of existing box enclosure depending on interface selection and machine configuration.
6. PLC Processor or Firmware upgrade may be necessary.

Upgrade Those Old Operator Interfaces

Machines	Old Interface	New Upgraded Interface
ADD, KRDIle	PanelMate 1000, Pots	PanelView 1000 ,1250 Standard/Plus
Pan-O-Mat Plus	PanelMate(s) 1000,1500,3000, Potentiometer Control	PanelView 1000, 1250 Standard/Plus
ABS Bun System	Potentiometer Control	PanelView 1000,1250 Standard/Plus

Headquarters:
 2115 Laburnum Ave.
 Richmond, Virginia 23227
 Tel: 1-800-255-3771
 or 1-804-355-7961
 Fax: 1-804-342-9724
sales@amfbakery.com

Europe Office:
 6 The Sidings,
 Station Road, Guiseley
 Leeds LS20 8BX
 England
 Tel: 44 (0) 1943 875703
 Fax: 44 (0) 1943 871806
sales-europe@amfbakery.com

Asia Office:
 Room 15-2, A-Building,
 Thuniss Dev. Building,
 No.11 Hui Xin East Street,
 Chaoyang District
 Beijing, China 100029,
 P.R. China
 Tel: 86-10-64823613
 Fax: 86-10-64934259
sales-asia@amfbakery.com

AMF's focus on continuous improvement may result in changes to machinery specifications without notice.

FOR MORE INFORMATION PLEASE CALL YOUR ACCOUNT MANAGER OR

1-800-BAKERS-1

www.amfbakery.com